

# WeatherTuff®

Building Surface Solutions

## SEALERCOAT

High build Elastomeric Waterproofing Coating



For all Building Exterior Surfaces & Terraces

### About Sealercoat

SEALERCOAT is an elastomeric, flexible single pack waterproofing membrane made out of 100% pure acrylic polymers under the technical collaboration of M/s Insulating Paints Inc Australia. It is used to fill Hair line cracks on walls and terrace. It's gives a smooth and sheen finish to all surfaces. It has been tested by G.E.R.I. Vadodara & National Test House Calcutta.

### Advantages

- Gives excellent waterproofing
- It is washable and Scrub resistant
- It eliminates the requirement of any other primer coat.
- Excellent resistance to algae and fungus
- Being elastic in nature it allows minor structural movements.

### Coverage Area

On Smooth Surface, 1Kg Sealercoat Covers Approximately 20 sqft in 2 coats.

### Applied

It can be apply for Galvanize/ Asbestos Sheet and also for R.C.C & Cement Surfaces.

# WeatherTuff®

Building Surface Solutions

## Application Method:

### For R.C.C. & Cement surfaces & Asbestos sheet

**Surface Preparation:** Clean the surface with adequate quantity of water. Make surface dust & grease free; remove all previous coatings which may have loose bond with the surface. If required, scrub with wire brush or use scrapper to remove old flake, chips & dust.

**Filling of Cracks:** Weather cracks are the cause of water/leakages thru wall and roofs of buildings. In case of a presence of prominent surface cracks please fill up the cracks with Diamond shield or any good quality crack filler before applying sealercoat

**Primer Coat:** Old, uneven and highly porous cement surfaces absorb essential polymers of Sealercoat. Hence- apply one or two coats of Sealoxo Primer or any other water based Undercoat for the best results and good finish.

**Final Finish:** Apply two Coats of Diluted Sealercoat with 15% water & should be applied with an interval of 3 to 4 hours between two coats.

## For Any Metal Sheet:

**Surface Preparation:** Clean the surface and make it dust, grease & Oil free and then apply a coat of good quality zinc phosphate primer to avoid corrosion of the metal sheet.

**Joint Filling:** Between the overlaying joints of Galv. / Asb. Sheets, insert cotton bedding or gauze, soaked & dipped in un diluted Sealercoat for at least 2 inch in depth. (Length wise). Galvanized "J" bolts may be covered with cotton gauze dipped in undiluted Sealercoat & liberally wrapped around the bolt to cover sufficient area.



### Marketed By WeatherTuff Pvt Ltd.

202, Sarthak Complex II, Nr. Swastik Cross Road, Navrangpura, Ahmedabad- 380009 .(Gujarat) INDIA.

Ph: 91-79-2656 2100 Telefax : 91-79-2656 4777

### Manufactured By Chitra Insultec Pvt Ltd.

3703/D, Phase 4, GIDC, Vatva, Ahmedabad- 382445. (Gujarat) INDIA